



### GENERAL DESCRIPTION

ENVIROSOLV™ is a water-based ink cleaner designed for the removal of water-based and plastisol inks. This product works especially well at opening up dried-in water-base ink in the image area. This product will protect the fabric from deep stains or ghosting from the image print.

### ADVANTAGES

- Water Based
- No Residue
- Pleasant Odor

### APPLICATIONS

Always card excessive ink from screen. Use one of the following applications.

#### "PRESS WASH/SCREEN OPENER"

Apply product on both sides of screen and then wipe or squeegee off until all residue is gone. ENVIROSOLV™ works extremely well when cataloging the screen.

#### "SCREEN WASH"

Apply to the ink side of the screen. Use a brush or pad to agitate both sides of the screen. High pressure water rinse until all residue is gone.

### Quick Tip:

To cut down on the number of rags it takes to clean a screen, use a non absorbent scrub pad to liquify the ink and a squeegee to pull all the ink to one end of the screen and wipe up with one or two rags.

*Polypropylene EconoBooth*



Look For More Information on all the Products in the ENVIROLINE™ of "Green" Chemistry.

